

# Datenblatt - Fiche technique - Data sheet **14.99.3430**



VALUE VGA-Verlängerung via TP, max. 180m

VALUE Prolongateur VGA via TP, 180 m

VALUE VGA Extender over Twisted Pair, 180 m

# VGA EXTENDER





(14.99.3430)

# **USER MANUAL**

V1.0

# Package Contents-

- VGA-L Local Unit
- VGA-R Remote Unit
- 1 user manual
- 2 power adapter DC 12V/600mA
- 1 1.2M cable (HD-15 Male to Male)

Anything missed, please contact with your vendor.

## **Features**

- The extension of VGA signal is up to 180 meter away by using the VGA Extender and one CAT.5 cable.
- Equalization length is adjustable.
- VGA signal gain is adjustable.

**Specifications** 

Function	VGA-L	VGA-R
VGA In/Out Connector	HD-15 Female x 1	
RJ-45 Connector	1	
Max. Resolution	1280x1024 60Hz	
Cable Distance	180 m (Max.)	
Power Adapter (Min.)	DC 12V 600mA	
Housing	Metal	
Weight	135g	140g
Dimensions (LxWxH)	92x34x22 mm	

## **LOCAL FRONT VIEW**



- 1. Power jack
- 2. Power LED
- 3. CAT.5 (RJ-45 Connector)

## **LOCAL REAR VIEW**



1. VGA In (HD-15 Female Connector)

## **REMOTE FRONT VIEW**



- 1. Power jack
- 2. Power LED
- 3. CAT.5 (RJ-45 Connector)

#### REMOTE REAR VIEW



1. VGA Out (HD-15 Female Connector)

#### **REMOTE BOTTOM VIEW**



- 1. EQ Equalization length adjust (Adjust it and weak characters be sharp)
- 2. GAIN Adjust brightness

## Installation

- 1. Turn off the PC.
- 2. Connect 14.99.3430 Local Unit HD-15 female connector with HD-15 male to male cable from PC.
- 3. Connect the 14.99.3430 Local and Remote Unit with CAT.5 cable.
- 4. Connect 14.99.3430 Remote Unit HD-15 female connector with HD-15 male to male cable from monitor.
- 5. Connect the power cord each side.
- 6. Turn on the monitor and PC.