Digital to Analog Audio Converter

User Manual Ver: 1.0

All brand names and trademarks are properties of their respective owners

Dear Customer

Thank you for purchasing this Audio Converter.

For optimum performance and safety, please read these instructions carefully before connecting, operating or adjusting this product. Please keep this manual for future reference.

INTRODUCTION:

This Digital to Analog Audio Converter is designed for either home or professional audio switching. It converts Coaxial or Toslink digital audio signals to analog L/R audio and available for connection to an external device such as an amplifier via standard RCA-style jacks. This Converter is samll in size and quite easy to install.

FEATURES:

This Converter has many features that enable it to perform in a superior manner. Among those features you will find:

- Converts Coaxial or Toslink digital audio signals to analog L/R audio.
- Supports sampling rate at 32,44.1,48 and 96KHz.
- 24-bit S/PDIF incoming bit stream on left and right channels.
- Provides electromagnetic-noise-free transmission.
- Easy to install and simple to operate.

S

SPECIFICATIONS:

User Manual	AC Power Adapter Ut	Accessories Adapter	Power Supply	Converter Unit	Regulatory Approvals	Power Consumption	External Power Supply	Power Requirement	Storage Humidity 5	Storage Temperature	Operating Humidity 10	Operating Temperature	Environmental	Limited Warranty	Warranty	Weight	Size(L-W-H)	Mechanical	Sampling rate	Output Audio Connector	Input Audio Connector	Connector	Output Audio	Input Audio	oigilai iiibuts/outbut
English Version	US standard,UK standard and so on		UL,CE,FCC	FCC,CE,UL		0.5watts(max)	5V DC@2A		5% to 90 % RH (no condensation)	-10°C to +80°C	10% to 85 % RH (no condensation)	0 °C to +70°C		1 Year Parts and Labor		78g	51X41X26MM		32,44.1,48 and 96KHz	2XRCA(R/L)	Toslink、1XRCA(Coaxial)		L/R audio	Coaxial or Toslink digital audio	

Note: Specifications are subject to change without notice.

PACKAGE CONTENTS:

and make sure the following items are contained in the shipping carton: Before attempting to use this unit, please check the packaging

- Main unit(Digital to Analog Audio Converter)
- 5V/DC Power Supply.
- User's Manual

PANEL DESCRIPTIONS:

signal input(s),output(s) and power requirements. Study the panel drawings below and become familiar with the


Coaxial Power Toslink


0

Back Panel:

Upper Panel:

Front Panel:





PANEL DESCRIPTIONS:

Before installation, please make sure all devices you wish to connect have been turned off.

- Connect the audio source device to the Converter using appropriate Toslink or Coaxial cables.
- 2) using appropriate L/R cable. Connect the A/V Receivers or Amplifiers to the Converter
- Insert the DC side of 5V power supply into the converter wall outlet. and then connect the AC side of the power supply into the

 ω

same time, the product will give priority to Toslink input. Note: When connected to the Toslink and Coaxial cables at the

CONNECTION DIAGRAM:

